

FUKOU

外径凹凸検出器

取扱説明書

尺寸图


富光計器株式会社

〒335-0014 埼玉県戸田市喜沢南1-7-6


TEL : 048-433-1779

外形图：


① FK-0501A：




② FK-0503B：




③ FK-2003B :



④ FK-3003B :



⑤ FK-5003B :



⑥ FK-2P10(電源カバー) : INPUT : AC220V OUTPUT : DC+/-15V

